



INSTALLATION RECOMMENDATIONS

- (1) All Floorworks planks and tiles should be acclimatized to the room temperature of the room they are to be laid in 24 hours prior to allow them to relax before installation starts.
- (2) It is recommended that your installer dry cut Floorworks planks and tiles to fit the floor area before spreading the adhesive on the floor.
- (3) All floor substrates eg: concrete, wood, MDF, partical board or any other porous surfaces **MUST** be primed first with **GILTGRIP WB FLOORING PRIMER**
- (4) We recommend that you cover all windows in the area to be installed to prevent direct sunlight from enhancing natural curing time of the adhesive. This will also help prevent the acclimatized temperature of the tiles and planks from changing.
- (5) All Floorworks planks and tiles **MUST** be installed with **GILTGRIP BOSTIK UNIVERSAL PREMIUM ACRYLIC ADHESIVE**

FAILURE TO FOLLOW THESE 5 STEPS WILL HINDER YOUR INSTALLERS CHANCE OF A SATISFACTORY INSTALLATION AND COULD VOID THE MANUFACTURES WARRANTY